



ASSEMBLY INSTRUCTION

SHELF BOXY / ROMB




radis

WWW.RADIS.EE



	S	M	L
BOXY4 -	8	12	16
BOXY5 -	10	16	22
BOXY6 -	12	18	24

	S	M	L
BOXY4 -	64	96	128
BOXY5 -	80	124	176
BOXY6 -	96	144	192



X2


X1

	S	M	L
BOXY4 -	24	36	48
BOXY5 -	30	46	60
BOXY6 -	36	54	72


BOXY4 - 4 LEVELS
 BOXY5 - 5 LEVELS
 BOXY6 - 6 LEVELS

BOXY - S - 89 CM
 BOXY - M - 140 CM
 BOXY - L - 193 CM


1



2




3




IMPORTANT:
REPEAT UNTIL UPPER SHELF

4



5





IMPORTANT:
FIX THE SHELF
TO THE WALL

