


ASSEMBLY INSTRUCTION

SHELF PIX / STEP




radis

WWW.RADIS.EE



	XS	S	M	L
PIX4 -		8	12	16
PIX5 -		10	16	22
PIX6 -	6	12	18	24

	XS	S	M	L
PIX4 -		64	96	128
PIX5 -		80	124	176
PIX6 -	48	96	144	192



X2


X1

	XS	S	M	L
PIX4 -		24	36	48
PIX5 -		30	46	60
PIX6 -	24	36	54	72


PIX4 - 4 LEVELS
 PIX5 - 5 LEVELS
 PIX6 - 6 LEVELS

PIX - XS - 54 CM
 PIX - S - 89 CM
 PIX - M - 140 CM
 PIX - L - 193 CM


1



2




3




IMPORTANT:
REPEAT UNTIL UPPER SHELF

4



5





IMPORTANT:
FIX THE SHELF
TO THE WALL

