
ASSEMBLY INSTRUCTION


SIDEBOARD PIX 4X4




radis

Nordic Elegance

WWW.RADIS.EE




X12



X12



X24




X12




X14



X48



X1




FOR CENTER DOORS X14




X2

1





2




3

IMPORTANT!
NO DOOR HINGES HOLES.







4




5




6



7




8





24X

9



10






IMPORTANT FOR CENTER DOORS:

USE HINGES AND SCREWS
FROM LABELED BAG “CENTER DOORS”



11





IMPORTANT:

FIX THE SIDEBOARD
TO THE WALL